


Installation Instructions Welding adapter

efector600


E30108

UK





Installation





- 1. Weld in the adapter.
 - The adapter should only be welded by qualified personnel.
 - ▶ Use a welding method which is suitable for the material (stainless steel, material no. 316S12).
 - ► Make sure that the adapter does not warp.
 - ► Let the adapter cool down.
- 2. Grease the following parts: nut (1), clamping ring (2), thread and inner hole of the adapter (3).
- 3. Position the clamping ring.
 - ? Chamfered end (4) into the adapter.
- 4. Screw in the nut.
- 5. Position the sensor (5).
- 6. Tighten the nut manually and mark its position with a line (6).
- 7. Adjust the sensor to the required installation depth. Hold it and tighten the nut by 1 full turn with a tool.

Repeated mounting

You can remove the sensor e.g. to clean the tip. Then insert the sensor again and firmly tighten the nut.







A: Grease

