

# CE

#### Operating instructions Diffuse reflection sensor

#### efector200


**O6T3** 

UK

2015



O6T3IO / 00 01 / 2



## **1** Preliminary note


### **1.1 Symbols used**

- Instruction
- Reaction, result >
- Designation of pushbuttons, buttons or indications [...]
- **Cross-reference**  $\rightarrow$ 
  - Important note
- Non-compliance can result in malfunctions or interference.

## **2** Functions and features


The diffuse reflection sensor detects objects and materials without contact and indicates their presence by a switching signal.

## **3** Installation



- Align the diffuse reflection sensor to the object to be detected.
- Secure it to a bracket.

## **4 Operating and display elements**



- 1: LED yellow switching output active
- 2: Setting potentiometer "sensitivity"
- 3: LED green operation, stability indication
- 4: Selector "output function"

### 4.1 Stability indication

The green LED is lit when the supply voltage is applied and there is sufficient excess gain. Under these conditions the sensor receives a stable signal.

stable signal	switch point	stable signal

Light-on mode					
LED green	on	off	off	on	
LED yellow	on	on	off	off	
Dark-on mode					
LED green	on	off	off	on	
LED yellow	off	off	on	on	

3


UK

## **5** Electrical connection


- The unit must be connected by a qualified electrician.
  - The national and international regulations for the installation of electrical equipment must be adhered to.
    - Ensure voltage supply to EN 50178.
- Disconnect power.
- Connect the unit as follows:

## 5.1 PNP

#### **Connector M12 pigtail**





Cable \*



**Connector M8 3-pin** 

**Connector M8 4-pin** 






\* Core colours: BN = brown, BU = blue, BK = black


## 5.2 NPN

#### **Connector M12 pigtail**




**Connector M8 3-pin** 

Cable \*




#### **Connector M8 4-pin**




\* Core colours: BN = brown, BU = blue, BK = black

## 6 Settings

#### 6.1 Set the output function



#### 6.2 Set the sensitivity



- Increase sensitivity: turn the setting screw of the potentiometer clockwise.
- Decrease sensitivity: turn the setting screw of the potentiometer anti-clockwise.

## 7 **Operation**

- Check whether the unit operates correctly.
- > The green LED is lit when the sensor is ready for operation.
- Dark-on mode: the output is switched / the yellow LED is lit when no object is > detected.
- Light-on mode: the output is switched / the yellow LED is lit when an object is > detected.

## 8 IO-Link

### 8.1 General information

This unit has an IO-Link communication interface which requires an IO-Linkcapable module (IO-Link master) for operation.

The IO-Link interface enables direct access to the sensor values and parameters and provides the possibility to set the parameters of the unit during operation. In addition communication is possible via a point-to-point connection with a USB adapter cable.

You will find more detailed information about IO-Link at www.ifm.com/uk/io-link.

#### 8.2 Device-specific information

You will find the IODDs necessary for the configuration of the IO-Link unit and detailed information about sensor values, diagnostic information and parameters in the overview table at www.ifm.com/uk/io-link.

#### 8.3 Parameter setting tools

You will find all necessary information about the required IO-Link hardware and software (e.g. ifm LINERECORDER SENSOR ZGS210) at www.ifm.com/uk/io-link.

## 9 Maintenance, repair, disposal

- Keep the lens of the sensor free from soiling.
- For cleaning do not use any solvents or cleaning agents which could damage the plastic parts.
- After use dispose of the unit in an environmentally friendly way in accordance with the applicable national regulations.
- Faulty sensors must only be repaired by the manufacturer.

Technical data and further information at unter www.ifm.com