




Operating instructions 5-segment signal lamp

DV15x0 DV25x0 UK



05 / 2017

Contents

1	Preliminary note	
2	Safety instructions	.5
	Functions and features 3.1 IO-Link 3.1.1 General information 3.1.2 Device-specific information	.6 .6
4	Installation	.6
5	Electrical connection5.1 IO-Link connection	
	Pin connection 6.1 IO-Link device 6.2 Standard unit	.8
7	Operating and display elements	.9
	Operation	10 10 10 11
	Parameter setting	13 13
	1 Scale drawing 1 10.1 DVx500 1 10.2 DVx510 1 10.3 DVx520 1 10.4 DVx530 1	16 17 18 19
ľ	Technical data2	

11.1 IO-Link device	20
12 Maintenance, repair and disposal	21
12.1 Cleaning the housing surface	
13 Approvals/standards	21

1 Preliminary note

Technical data, approvals, accessories and further information at www.ifm.com.

1.1 Symbols used

- Instructions
- > Reaction, result
- [...] Designation of keys, buttons or indications
- → Cross-reference
- Important note
 Non-compliance may result in malfunction or interference.
- Information Supplementary note.

A WARNING

Warning of serious personal injury.

Death or serious irreversible injuries may result.

▲ CAUTION

Warning of personal injury.

Slight reversible injuries may result.

NOTE

Warning of damage to property

2 Safety instructions

- Read this document before setting up the product and keep it during the entire service life.
- The product must be suitable for the corresponding applications and environmental conditions without any restrictions.
- Only use the product for its intended purpose(→ 3 Functions and features).
- If the operating instructions or the technical data are not adhered to, personal injury and/or damage to property may occur.
- The manufacturer assumes no liability or warranty for any consequences caused by tampering with the product or incorrect use by the operator.
- Installation, electrical connection, set-up, operation and maintenance of the product must be carried out by qualified personnel authorised by the machine operator.
- Protect units and cables against damage.

3 Functions and features

The unit is used for the visual display of machine conditions. The versions DVx510 and DVx530 additionally have a buzzer for acoustic signalling.

The 5 LED segments and the audible warning device can be switched on and off individually.



The unit is intended for indoor use only. Observe the operating conditions (→ 11 Technical data).



► The unit must not be used for safety-related applications such as access control.

The standard units are DV15xx. The DV25xx units are IO-Link devices. The IO-Link version can be triggered and configured via the standard IO-Link interface. With the standard version the individual LED segments can be switched individually via digital inputs. Parameters are set via a parameter setting button or via an additional IO-Link interface.

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

3.1 IO-Link

3.1.1 General information


This unit has an IO-Link communication interface which enables direct access to process and diagnostic data. In addition it is possible to set the parameters of the unit while it is in operation. Operation of the unit via an IO-Link interface requires an IO-Link capable module (IO-Link master).

3.1.2 Device-specific information

With a PC, suitable IO-Link software and an IO-Link adapter cable communication is possible when the system is not in operation. The IODDs necessary for the configuration of the unit, detailed information about process data structure, diagnostic information, parameter addresses and the necessary information about the required IO-Link hardware and software can be found at www.ifm.com.

4 Installation

- ► Disconne
 - ▶ Disconnect power before installation.
- ► For installation choose a flat mounting surface.



Fixture (view from bottom)

- 1: Front
- ► Attach the fixture for the unit to the mounting surface using the supplied M4 nuts. Tightening torque 1.8 Nm.
- ➤ Only with the models DVx500 and DVx510: For mounting on a horizontal surface attach the base to the fixture (overlapping marks on base and fixture) and turn clockwise by approx. 10 ° to fix it. For mounting on a vertical surface loosen the screw in the base, turn the upper

part of the base by 180 ° and tighten the screw again. Attach the base to the fixture (overlapping marks on base and fixture) and turn clockwise by approx. 10 ° to fix it.

- ▶ Insert the cable through the fixture and, if necessary, the base and connect the socket with the M12 connector in the signal lamp. Tightening torque max. 1 Nm.
- ► Attach the signal lamp to the fixture or the base (overlapping marks) and turn clockwise by approx. 10 ° to fix it.
- Observe the maximum tightening torque of the connection cables.
- Integrated seals at the bottom of the fixture and in the base as well as O-rings at the fixture and base prevent ingress of moisture.

More information about available accessories at www.ifm.com

5 Electrical connection

The unit must be connected by a qualified electrician.

The national and international regulations for the installation of electrical equipment must be adhered to.

Voltage supply according to SELV, PELV

- ▶ Disconnect power.
- ► Connect the unit.

5.1 IO-Link connection

The IO-Link port must be connected according to the IO-Link specification.

6 Pin connection

6.1 IO-Link device

M12 connector IO-Link, 4 poles

(4 x 0.34 mm² / AWG 22)

- 1: UB+
- 2: not connected
- 3: UB-
- 4: IO-Link




6.2 Standard unit

M12 connector, 8 poles

(8 x 0.25 mm² / AWG 24)

- 1: LED segment 5
- 2: buzzer (DV1510 and DV1530)
- 3: LED segment 3
- 4: LED segment 2
- 5: voltage supply
- 6: LED segment 1
- 7: LED segment 4
- 8: IO-Link






The input polarity is selectable.

- ► Connect pin 5 to +24 V DC to trigger the inputs with a NPN transistor.
- Connect pin 5 to GND to trigger the inputs with an PNP transistor.

UK

7 Operating and display elements



8 Operation

8.1 Operation of the IO-Link version

8.1.1 General

The unit is connected to an IO-Link master (A port) with a 3-pole connection cable. The controller switches the individual LED segments on and off in the configured colours according to the set parameters.

Via the parameter "Operating mode" the following modes can be set:

- On/off mode
- RGB mode
- Analogue mode

8.1.2 On/off mode

While in operation the controller switches the 5 LED segments and the buzzer (only with DVx510 and DVx530) on and off (PDout, cyclical data communication). Signalling corresponds to the pre-defined parameters for the individual LED segments and the buzzer.

Via the acyclic parameter setting the following properties can be set for every LED segment:

- Colour (red, green, yellow, blue, violet, turquoise, white, off)
- Frequency (permanently on, low flash rate slow/medium/fast, high flash rate slow/medium/fast)
- Brightness (100 %, 75 %, 50 %, 25 %)

For the models with an acoustic signal device the audibility of the buzzer can be set.

7	6	5	4	3	2	1	0	PDout
			Seg. 5	Seg. 4	Seg. 3	Seg. 2	Seg. 1	Byte 0
								Byte 1
								Byte 2
								Byte 3
								Byte 4
							Buzzer	Byte 5

8.1.3 RGB mode

While in operation the controller switches the 5 LED segments and the buzzer on and off (only with DVx510 and DVx530), defining the respective properties (PDout, cyclical data communication).

In this operating mode 8 different acoustic signals are available for the buzzer.

7	6	5	4	3	2	1	0	PDout
	Segme	nt 1 LED pro	perties		Seg. 1 red	Seg. 1 green	Seg. 1 blue	Byte 0
	Segme	nt 2 LED pro	perties		Seg. 2 red	Seg. 2 green	Seg. 2 blue	Byte 1
	Segme	nt 3 LED pro	perties		Seg. 3 red	Seg. 3 green	Seg. 3 blue	Byte 2
	Segme	nt 4 LED pro	perties		Seg. 4 red	Seg. 4 green	Seg. 4 blue	Byte 3
	Segme	nt 5 LED pro	pperties		Seg. 5 red	Seg. 5 green	Seg. 5 blue	Byte 4
	Buzzer	sound (buzz 18)	zer style				Buzzer	Byte 5

8.1.4 Analogue mode

While in operation the controller transmits an analogue value between 0 and 100 % in byte 0 via PDout. Byte 1 determines the representation of the visual signalling. 9 different representations are possible.

Byte 5 defines the acoustic signal (only with DVx510 and DVx530). 8 different acoustic signals are available.

7	6	5	4	3	2	1	0	PDout				
	Analogue value 0100 %											
				Rep	resentation	LED (style 1	9)	Byte 1				
								Byte 2				
								Byte 3				
								Byte 4				
	Buzzer	sound (buzz	zer style				Buzzer	Byte 5				

The signal lamp generates the following visual indications of the analogue value depending on the data in byte 1.

Analogue v	value: 0 %	1-9 %	10-19 %	20-29 %	30-39 %	40-49 %	50-59 %	60-69 %	70-79 %	80-89 %	90-99 %	100 %	
Style 1	alue. U /II	1-5 /0	10-13 /0	white	white	white	white white	white white	white white white	white white white white	white white white white	white white white white	Segment 1 Segment 2 Segment 3 Segment 4
	white	white	white	white	white	white	white	white	white	white	white	white	Segment 5
Style 2	white	white	white	white	white	white white	white white	white white white white	white white white white	white white white white white	white white white white white	white white white white white white	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5
Style 3	white	white	white	white white	white white	white white	white white	white white white white	white white white white	white white white white white	white white white white white	white white white white	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5
Style 4	white	white	white	white white	white	white white	white white	white white white	white white white white	white white white white white white	white white white white white	white white white white white	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5
Style 5	green green green green	green green green green	green green green blue	green green blue green	green green blue green	green blue green green	green blue green green	green green green green	green green green green	green green green green	green green green green	green green green green	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5
Style 6	red red red red blue	red red red red blue	red red red red blue	red red red blue red	red red line line line line line line line line	red red blue red red	red red blue red red	red blue red red red	red blue red red red	red red red	red red red	red red red	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5
Style 7	yellow yellow yellow yellow blue	yellow yellow yellow yellow blue	yellow yellow yellow yellow blue	yellow yellow yellow blue yellow	yellow yellow yellow blue yellow	yellow yellow yellow yellow	yellow yellow blue yellow yellow	yellow yellow yellow yellow	yellow yellow yellow yellow	yellow yellow yellow yellow	yellow yellow yellow yellow	yellow yellow yellow yellow	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5
Style 8	white	white	white	white white	white white	white white	white white	white white white	white white white white	white white white white	white white white white white	white white white white white	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5
Style 9	white	white	white	white	white	white white	white white	white white white	white white white	white white white white white	white white white white white	white white white white white	Segment 1 Segment 2 Segment 3 Segment 4 Segment 5

8.2 Operation of the standard version

The unit is connected to the digital outputs of the controller via an 8-pole cable (see accessories at www.ifm.com). The 6 HTTL inputs of the signal lamp are triggered with 24 V DC. According to the set parameters the 5 LED segments are on and the buzzer sounds (only with DVx510 and DVx530).

The signal inputs can be triggered either in PNP or in NPN technology (\rightarrow 6.2 Standard unit).

With the parameter setting button the following properties can be set for every LED segment:

- Colour (red, green, yellow, blue, violet, turquoise, white, off)
- Frequency (permanently on, low flash rate slow/medium/fast, high flash rate slow/medium/fast)
- Brightness (100 %, 75 %, 50 %, 25 %)

Parameter setting via the IO-Link interface (pin 8 of the M12 connector) is also possible.

After parameter setting the unit goes to the Run mode.

9 Parameter setting

9.1 IO-Link version

The unit can be configured using an IO-Link parameter setting tool (e.g. LR DEVICE) (\rightarrow 3.1 IO-Link).

More information is given in the IODD at www.ifm.com.

9.2 Standard version

- ► Turn the transparent protective cover anticlockwise by approx. 10 ° and remove it.
- ▶ Briefly press the parameter setting button at the head of the unit (< 5 s).
- The feedback LED is green on.
 The unit is in the parameter setting mode.
- ▶ Briefly press the parameter setting button (< 5 s) to go to the next parameter.
- ▶ Press the parameter setting button for a longer time (> 5 s) to set the selected parameter.


- > The feedback LED flashes green.
 The unit indicates the current settings of the LED segment to be configured.
- ▶ Briefly press the parameter setting button (< 5 s) to change the value for the selected parameter. Repeat this step until the requested setting is selected.
- > The unit indicates the current settings of the LED segment to be configured.
- ▶ Press the parameter setting button for a longer time (> 5 s) to save the selected value for this parameter.
- > The feedback LED flashes green.
 The unit saves the value and goes to the next parameter.
- > After configuration of all LED segments the unit displays the current settings of all LED segments.
- ▶ Briefly press the parameter setting button (< 5 s) to finish the parameter setting mode.</p>
- > The feedback LED goes out. The unit is in the Run mode.
- If the parameter setting button is not pressed for longer than 30 seconds, the unit saves the last changes and goes to the Run mode.


9.2.1 Parameter structure

LED seg.	Parameters	Value								
1	Colour	Colour red green		yellow	blue	violet	turquoise	white	off	
	Frequency	on	low flash rate slow	low flash rate medium	low flash rate fast	high flash rate slow	high flash rate medium	high flash rate fast		
	Brightness	100 %	75 %	50 %	25 %					
2	Colour	red	green	yellow	blue	violet	turquoise	white	off	
	Frequency	on	low flash rate slow	low flash rate medium	low flash rate fast	high flash rate slow	high flash rate medium	high flash rate fast		
	Brightness	100 %	75 %	50 %	25 %					
3	Colour	red	green	yellow	blue	violet	turquoise	white	off	
	Frequency	on	low flash rate slow	low flash rate medium	low flash rate fast	high flash rate slow	high flash rate medium	high flash rate fast		
	Brightness	100 %	75 %	50 %	25 %					
4	Colour	red	green	yellow	blue	violet	turquoise	white	off	
	Frequency	on	low flash rate slow	low flash rate medium	low flash rate fast	high flash rate slow	high flash rate medium	high flash rate fast		
	Brightness	100 %	75 %	50 %	25 %					
5	Colour	red	green	yellow	blue	violet	turquoise	white	off	
	Frequency	on	low flash rate slow	low flash rate medium	low flash rate fast	high flash rate slow	high flash rate medium	high flash rate fast		
	Brightness	100 %	75 %	50 %	25 %					


10 Scale drawing


10.1 DVx500





10.3 DVx520





11 Technical data

		DV1500	DV1510	DV1520	DV1530	DV2500	DV2510	DV2520	DV2530	
Operating voltage DC	[V]		ı	1	18.	30				
Nominal voltage DC	[V]				2	4				
Current consumption	[mA]		<u>≤</u>	200 RI	MS (40)	0 mA fo	or 50 m	s)		
Input current	[mA]		typ. 6 (24 V DC, high signal)							
Pollution degree	2									
Ambient temperature	[°C]	C] -2550								
Storage temperature	[°C]	-4075								
Maximum permissible relative humidity	[%]	90								
Maximum operating altitude	[m]		2000 above sea level							
Permissible air pressure	[hPa]	1060								
IO-Link		• •				•				
Connectors		M12	conne	ctor, 8 p	ooles	M12	connec	ctor, 4 p	ooles	

11.1 IO-Link device

Transmission type		COM2 (38.4 kbaud)
IO-Link revision		1.1
SDCI standard		IEC 61131-9
IO-Link device ID		
DV15xx		850 d / 00 03 52 h
DV25xx		841 d / 00 03 49 h
SIO mode		yes
Input load current at input C/Q to V0 (ILL)	[mA]	< 250
Required master port type		A
Min. process cycle time	[ms]	3.2

UK

12 Maintenance, repair and disposal

The unit is maintenance-free.

After use dispose of the unit in an environmentally friendly way in accordance with the applicable national regulations.

12.1 Cleaning the housing surface

- ▶ Disconnect the unit.
- ► Clean the unit from dirt using a soft, chemically untreated and dry cloth.
- ► In case of heavy dirt, use a damp cloth.



Micro-fibre cloths without chemical additives are recommended.

13 Approvals/standards

EC declarations of conformity, approvals, etc. at www.ifm.com