Diffuse mode sensor

CE 🚷 IO-Link

Model Number

OBD1100-R101-2EP-IO-V31-IR

Diffuse mode sensor

with 4-pin, M8 x 1 connector

Features

- Miniature design with versatile moun-• ting options
- Extended temperature range ٠ -40°C ... 60°C
- High degree of protection IP69K .
- IO-link interface for service and pro-• cess data
- Infrared light design ٠


Product information

The R101 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.


The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.



18.3 6.6


Electrical connection



Pinout



Indicators/operating means



1	Light-on/dark-on changeover switch			
2	Sensitivity adjuster			
3	Operating indicator / dark on			
4	Signal indicator			
5	Operating indicator / light on			
5	Operating indicator / light off			

Dimensions

OBD1100-R101-2EP-IO-V31-IR

Emitter

Receiver

205

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411

fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Pepperl+Fuchs Group

OBD1100-R101-2EP-IO-V31-IR

Technical data			Accessories
General specifications			IO-Link-Master02-USB
Detection range		2 1100 mm	IO-Link master, supply via USB port or se-
Detection range min.		10 60 mm	parate power supply, LED indicators, M12
Detection range max.		5 1100 mm	plug for sensor connection
Adjustment range		75 1100 mm	
Reference target		standard white, 100 mm x 100 mm	V31-WM-2M-PUR
Light source		LED	Female cordset, M8, 4-pin, PUR cable
Light type		modulated infrared light 850 nm	Vot CM OM BUD
LED risk group labelling Diameter of the light spot		exempt group	V31-GM-2M-PUR
Angle of divergence		approx. 100 mm at a distance of 1000 mm 5.4 $^{\circ}$	Female cordset, M8, 4-pin, PUR cable
Ambient light limit		EN 60947-5-2	Other suitable accessories can be found at
Functional safety related para	motors	EN 00347-5-2	www.pepperl-fuchs.com
MTTF _d	ineter 3	724 a	
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0%	
Indicators/operating means			
Operation indicator		LED green:	
		constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode	
Function indicator		LED yellow: constantly on - object detected	
Control elements		constantly off - object not detected Light-on/dark-on changeover switch	
Control elements		Sensing range adjuster	
Electrical specifications			
Operating voltage	UB	10 30 V DC	
Ripple	2	max. 10 %	
No-load supply current	I ₀	< 25 mA at 24 V supply voltage	
Protection class		III	
Interface			
Interface type		IO-Link (via C/Q = pin 4)	
Transfer rate		COM 2 (38.4 kBaud)	
IO-Link Revision		1.1	
Min. cycle time		2.3 ms	
Process data witdh		Process data input 1 Bit Process data output 2 Bit	
SIO mode support		yes	
Device ID		0x110101 (1114369)	
Compatible master port type		A	
Output			
Switching type		The switching type of the sensor is adjustable. The default set- ting is: C/Q - Pin4: NPN normally open / light-on, PNP normally closed /	
		dark-on, IO-Link /Q - Pin2: NPN normally closed / dark-on, PNP normally open / light-on	
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse pola-	
		rity protected, overvoltage protected	
Switching voltage		max. 30 V DC	
Switching current		max. 100 mA , resistive load	
Usage category		DC-12 and DC-13	
Voltage drop	U _d	≤ 1.5 V DC	
Switching frequency	f	1000 Hz	
Response time		0.5 ms	
Directive conformity Electromagnetic compatibility			
Directive 2014/30/EU		EN 60947-5-2/A1:2012	
Ambient conditions			
Ambient temperature		-40 60 °C (-40 140 °F)	Ť
Storage temperature		-40 70 °C (-40 158 °F)	a de la companya de l
Mechanical specifications			
Degree of protection Connection		IP67 / IP69 / IP69K	
		M8 x 1 connector, 4-pin	
Material		PC (Polycarbonate)	
Housing Optical face		PC (Polycarbonate) PMMA	
Mass		approx. 10 g	
Compliance with standards and directives			
Standard conformity			
Product standard		EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012	

Date of issue: 2016-11-18 267075-100421_eng.xml Release date: 2016-11-18 14:50

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Diffuse mode sensor

Standards


UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008 EN 61131-9:2013


Approvals and certificates


UL approval

E87056 , cULus Listed , class 2 power supply , type rating 1

Curves/Diagrams








Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



Functions and Operation



To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range /sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.

Pepperl+Fuchs Group

www.pepperl-fuchs.com

